

Pen digitizers: EMR, active pens and passive styluses

Chapter 10 | Reading 1 of 3



Resistive handheld: stylus input and a physical keyboard coexist.

Yuri Litvinenko from Kirov, Russia | [Source](#) | [CC BY 2.0](#). Unmodified photograph; scaled for display.

Three very different tools

A passive resistive stylus applies force. A passive capacitive stylus provides suitable electrical coupling and contact geometry. Neither automatically provides pen identity, hover, tilt or pressure information.

Wacom's EMR approach uses electromagnetic coupling between a sensor and a resonant pen. The sensor field can power a compatible battery-free pen. This differs from an active electrostatic pen communicating with a compatible capacitive sensor system.

The word 'active' is not enough to establish interoperability. Protocol, controller, firmware, operating system and application support must match. A pen that writes on one tablet may do nothing on another.

Pen digitizers: EMR, active pens and passive styluses

Chapter 10 | Reading 2 of 3

Coordinate, pressure and intent

Pen systems may report hover, tip contact, buttons, pressure and tilt, depending on the hardware and protocol. Position resolution and pressure levels describe reporting capability; they do not directly establish handwriting quality.

Inspect the first stroke, diagonal lines, slow curves and edge writing. Look for offset between displayed ink and the tip, jitter, delay and missing initial segments. Palm rejection should suppress unintended hand input while retaining intended pen behavior.

The animation separates the sensor's field, compatible pen response and reported position. It does not model electromagnetic field strength or pen power consumption.

Pen digitizers: EMR, active pens and passive styluses

Chapter 10 | Reading 3 of 3

Integrating pen and finger touch

A service tablet may need both gloved finger interaction and detailed annotation. Specify which gestures are permitted while a pen is in range and what happens when the pen battery is low or the pen is lost.

Check the final display stack and nearby metal for effects on the chosen pen system. Compare optical parallax with sensor-coordinate offset; calibrating coordinates cannot remove the physical distance between tip and image.

Test the intended application. A host may recognize a pen while the application ignores pressure or handles erasing incorrectly. Treat accessory replacement and protocol longevity as lifecycle requirements.

Apply the idea

A specification says 'supports stylus.' What clarification is essential?

Discussion: Identify passive resistive, passive capacitive, EMR or the exact active-pen protocol, then required pressure, hover, tilt, buttons, palm rejection and application behavior.

References:

S14 Wacom - [EMR and active electrostatic pen technologies](#)

S17 USB-IF - [HID specifications and usage tables](#)

S18 Microsoft - [Required touchscreen HID collections and reports](#)